

Installing Center Ring Insert

The center ring insert should be installed after the entire yurt has been set up.

1. Using a step ladder in the center of the yurt, slip the center ring insert into the underside of the center ring. Be sure the side of the center ring insert that has the screen attached to it faces upward. The center ring insert has been made to install around the dome opener bracket, so also be sure to line up this opening with the bracket.
2. Once it is in place, screw the center ring insert to the center ring with the screws provided at the five predrilled locations.
3. A screen patch has been included for installation to the underside of the center ring insert at the dome opener spindle location. It can be secured with staples or tacks. Before attaching it, mark and cut a small "x" into the screen for the dome opener spindle to protrude through.

