

Measuring Window Locations on Existing Side Cover

When ordering a replacement side cover or wall insulation we will need a full circumference of measurements. All measurements should be taken from the exterior of the yurt. We will need to know the total width of any door frames, the distances between the door(s) and windows and the width of windows (including the velcro frames).

Step 1

Measure the total width of the door frame.



Step 2

Measure from the outer edge of the door frame to the nearest edge of the velcro of the first window.



Step 3

Measure the total width of the window including the velcro frame.



Step 4

Measure the distance between the first window and the next window (to the outside of the velcro frame).



Step 5

Continue measuring the distances between all windows and doors as well as the width of all windows and door frames until you have the full circumference of the yurt documented. Your Pacific Yurts representative will need to know if the measurements you provide are going clockwise around the yurt, or counter-clockwise.

—EXAMPLE ONLY—

